

**TORO.**

## INSTALLATION INSTRUCTIONS

### S700 Rubber Cover Kit, 700-10

**1** Apply two beads of 3M Scotch-Grip 847 adhesive to underside of nozzle cover as shown.

**2** Position adhesive coated side of nozzle cover on top of nozzle as shown. Insert retainer plate pins through cover and press firmly into top of nozzle.

**3** Apply a bead of adhesive to underside of flange area on cap cover.

**4** To complete installation, position cap cover on cap as shown.

